NOTE: *Engine repair information is not contained within this tractor Repair Manual. For engine repair, refer to publication number 87515682 for the 8.3 & 9.0L 6 Cylinder, 24 Valve CNH Engine with High Pressure Common Rail Fuel System.*

STANDARD TORQUE SPECIFICATIONS .....SECTION 00, CHAPTER 1
TORQUE SPECIFICATIONS - METRIC HARDWARE 00-1-4
TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS 00-1-5
TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS 00-1-6

SAFETY, GENERAL INFORMATION, MAINTENANCE SCHEDULE .....SECTION 00, CHAPTER 2
SAFETY 00-2-3
GENERAL INFORMATION 00-2-5
LUBRICATION/MAINTENANCE CHART 00-2-6
SYSTEM CAPACITIES 00-2-7

ENGINE REMOVAL AND INSTALLATION .....SECTION 10, CHAPTER 1
ENGINE REMOVAL 10-1-3
ENGINE INSTALLATION 10-1-10

FUEL TANK / FUEL SENDER REMOVAL AND INSTALLATION .....SECTION 10, CHAPTER 2
SPECIAL TORQUES 3001-3
FUEL TANK REMOVAL AND INSTALLATION 3001-3
FUEL LEVEL SENDER REMOVAL AND INSTALLATION..... 3001-10

HOOD REMOVAL .....SECTION 10, CHAPTER 3
HOOD REMOVAL 10-3-3
HOOD INSTALLATION 10-3-5

COOLING SYSTEM MODULE REMOVAL AND INSTALLATION .....SECTION 10, CHAPTER 4
COOLING MODULE REMOVAL 10-4-3
COOLING MODULE INSTALLATION 10-4-7

VISCOUS FAN DRIVE TEST .....SECTION 10, CHAPTER 5
REQUIRED TOOLS 10-5-3
DIAGNOSTIC PROCEDURE 10-5-4
FAN SPEED TEST 10-5-7

POWERSHIFT TRANSMISSION SYSTEM -
HOW IT WORKS AND TROUBLESHOOTING .....SECTION 21, CHAPTER 1
TRANSMISSION SYSTEM INTRODUCTION 21-1-3
TRANSMISSION SYSTEM CONTROLS 21-1-5
TRANSMISSION SYSTEM COMPONENTS 21-1-6
TRANSMISSION LUBE AND DISTRIBUTION TUBES 21-1-8
POWERSHIFT TRANSMISSION CLUTCH LAYOUT 21-1-10
POWERSHIFT VALVE CLUTCH ENGAGEMENTS 21-1-11
POWER FLOW (FORWARD SPEEDS) 21-1-12
POWER FLOW (REVERSE SPEEDS) 21-1-30
POWER FLOW (FORWARD CREEPER DRIVE SPEEDS) 21-1-34
POWER FLOW (REVERSE CREEPER DRIVE SPEEDS) 21-1-40
INCHING VALVE OPERATION 21-1-42
INSTRUMENTATION CLUSTER - TRANSMISSION LEAKAGE CHECK 21-1-46
MASTER CLUTCH PRESSURE CHECK 21-1-49

FRONT FRAME TO SPEED TRANSMISSION SPLIT .....SECTION 21, CHAPTER 2
SPECIAL TOOLS 21-2-3
SPECIAL TORQUES 21-2-3
FRONT FRAME TO SPEED TRANSMISSION SPLIT 21-2-4

SPEED TO RANGE TRANSMISSION SPLIT ..... SECTION 21, CHAPTER 3
SPECIAL TOOLS 21-3-3
SPECIAL TORQUES 21-3-3
SPEED TO RANGE TRANSMISSION SPLIT 21-3-4
Removal 21-3-4
Installation 21-3-7

SPEED TRANSMISSION ..... SECTION 21, CHAPTER 4
SPECIFICATIONS 21-4-4
SPECIAL TORQUES 21-4-4
TROUBLESHOOTING AFTER SPEED TRANSMISSION REPAIR 21-4-4
SPECIAL TOOLS 21-4-5
SPEED TRANSMISSION WITH CREEP OPTION 21-4-6
ASSEMBLING THE COUNTERSHAFT WITH CREEPER SPEED CLUTCH 21-4-14
TRANSMISSION ASSEMBLY WITH CREEP OPTION 21-4-78
TRANSMISSION ASSEMBLY WITHOUT CREEP OPTION 21-4-80

RANGE TRANSMISSION TO REAR FRAME SPLIT ..... SECTION 21, CHAPTER 5
SPECIAL TOOLS 21-5-3
SPECIAL TORQUES 21-5-3
RANGE TRANSMISSION TO REAR FRAME SPLIT 21-5-4
Disassembly 21-5-4
Assembly 21-5-7

RANGE TRANSMISSION INCLUDING FWD CLUTCH/PARK BRAKE ..... SECTION 21, CHAPTER 6
SPECIFICATIONS 21-6-3
TROUBLESHOOTING AFTER RANGE TRANSMISSION REPAIR 21-6-3
SPECIAL TORQUES 21-6-3
SPECIAL TOOLS 21-6-4
RANGE TRANSMISSION 21-6-5
Removing the Shaft Master Clutch 21-6-5
Removing the Input Shaft, Countershaft and Mechanical Front Drive (FWD) / Park Brake Assembly 21-6-7
Disassembly of the Master Clutch 21-6-12
Exploded View of the Master Clutch 21-6-14
Assembly of the Master Clutch 21-6-15
Disassembly of the Range Transmission Input Shaft 21-6-16
Exploded View of the Range Transmission Input Shaft 21-6-22
Assembly of the Range Transmission Input Shaft 21-6-23
Cross-Section of Input Shaft 21-6-32
Disassembly of the Range Transmission Countershaft 21-6-33
Exploded View of the Range Transmission Countershaft 21-6-37
Assembly of the Range Transmission Countershaft 21-6-38
Front Wheel Drive (FWD) - Emergency Brake Disassembly 21-6-45
Exploded View of FWD and Emergency Brake 21-6-51
Assembly of the FWD / Emergency Brake 21-6-52
Exploded View of the Range Transmission Countershaft, Input Shaft, and FWD Input Shaft 21-6-66
Installing the Range Transmission Countershaft, Input Shaft,
and FWD Input Shaft into the Range Transmission Housing 21-6-67
SETTING THE END PLAY OF THE RANGE TRANSMISSION COUNTERSHAFT AND INPUT SHAFT 21-6-73
Installing the Range Input Master Clutch 21-6-75

TRANSMISSION CONTROL VALVES AND INCHING VALVE ..... SECTION 21, CHAPTER 7
SPECIAL TORQUES 21-7-3
POWERSHIFT TRANSMISSION CONTROL VALVES 21-7-3
TRANSMISSION CONTROL VALVE CONFIGURATION 21-7-4
INCHING VALVE 21-7-15

REAR FRAME ..... SECTION 21, CHAPTER 8
SPECIFICATIONS 21-8-3
SPECIAL TORQUES 21-8-3
SPECIAL TOOLS 21-8-3
DIFFERENTIAL 21-8-4
Removal 21-8-4
Disassembly 21-8-10
PINION SHAFT 21-8-14
Removal and Disassembly 21-8-14
Assembly and Installation 21-8-16
DIFFERENTIAL ASSEMBLY 21-8-24
DIFFERENTIAL INSTALLATION 21-8-29
ADJUSTING THE DIFFERENTIAL PRELOAD 21-8-35
ADJUSTING THE RING AND PINION BACKLASH 21-8-37
BEVEL PINION AND GEAR TOOTH CONTACT CHECK 21-8-38

HYDRAULIC PUMP DRIVE ..... SECTION 21, CHAPTER 9
SPECIAL TORQUES 21-9-3
SPECIFICATIONS 21-9-3
PUMP DRIVE 21-9-3
Removal 21-9-3
Disassembly 21-9-4
Assembly 21-9-7
Installation 21-9-12

FRONT WHEEL DRIVE CONTROL SYSTEM - HOW IT WORKS ..... SECTION 25, CHAPTER 1
FRONT WHEEL DRIVE (FWD) 25-1-3
ELECTRONIC FRONT WHEEL DRIVE (FWD) CONTROL 25-1-5
FRONT WHEEL DRIVE (FWD) CONTROL MODES 25-1-7
FRONT WHEEL DRIVE (FWD) FUNCTIONAL TESTS 25-1-8
TROUBLESHOOTING 25-1-10

DIFFERENTIAL LOCK CONTROL SYSTEM - HOW IT WORKS ..... SECTION 25, CHAPTER 2
DIFFERENTIAL LOCK 25-2-3
ELECTRONIC DIFFERENTIAL LOCK CONTROL 25-2-5
DIFFERENTIAL LOCK CONTROL MODES 25-2-7
DIFFERENTIAL LOCK CONTROL 25-2-8
DIFFERENTIAL LOCK FUNCTIONAL TESTS 25-2-9
TROUBLESHOOTING 25-2-12
TROUBLESHOOTING 25-2-14
PTO/DIFFERENTIAL LOCK VALVE CIRCUIT 25-2-15

FRONT WHEEL DRIVE OUTPUT SHAFT ..... SECTION 25, CHAPTER 3
SPECIAL TORQUES 25-3-3
FWD OUTPUT SHAFT 25-3-4
FWD Output Shaft Removal 25-3-4
FWD Output Shaft Disassembly 25-3-5
FWD Output Shaft Assembly 25-3-9

FRONT WHEEL DRIVE DRIVE SHAFT ..... SECTION 25, CHAPTER 4
SPECIAL TORQUES 25-4-3
FWD DRIVE SHAFT 25-4-4

SUSPENSION FWD AXLE SYSTEM - HOW IT WORKS AND TROUBLESHOOTING ..SECTION 25, CHAPTER 5
SUSPENDED FWD AXLE OPERATION 25-5-3
SUSPENDED MFD AXLE- CALIBRATION MODE 25-5-9
ERROR TABLE 25-5-11
SUSPENDED FWD AXLE- MANUAL OPERATION MODE (TEST MODE) 25-5-13
SUSPENDED FWD AXLE- DEMONSTRATION MODE 25-5-16

SUSPENSION FWD AXLE REMOVAL .....SECTION 25, CHAPTER 6
SUSPENDED FWD AXLE 25-6-3
Removal 25-6-3
Installation 25-6-5

SUPERSTEER AXLE REMOVAL AND INSTALLATION .....SECTION 25, CHAPTER 7
SPECIAL TORQUES 25-7-3
SPECIAL TOOLS 25-7-3
FRONT AXLE REMOVAL 25-7-4
FRONT AXLE INSTALLATION 25-7-7

LIMITED SLIP FWD DIFFERENTIAL.....SECTION 25, CHAPTER 8
SPECIFICATIONS 25-8-2
SPECIAL TORQUES 25-8-2
SPECIAL TOOLS 25-8-2
DIFFERENTIAL CARRIER ASSEMBLY REMOVAL 25-8-3
DIFFERENTIAL DISASSEMBLY 25-8-4
Pinion Disassembly 25-8-8
DIFFERENTIAL ASSEMBLY 25-8-11
DIFFERENTIAL CARRIER ASSEMBLY 25-8-15
Pinion Position and Assembly 25-8-15
Shim Pack Thickness Chart 25-8-16
Setting The Pinion Depth 25-8-17
Adjusting Bearing Preload 25-8-20
DIFFERENTIAL INSTALLATION 25-8-22
Checking Backlash 25-8-23
Ring Gear and Pinion Tooth Pattern Interpretation 25-8-25
Installation of Carrier Assembly to Axle Housing 25-8-27

LOCKING FWD DIFFERENTIAL.....SECTION 25, CHAPTER 9
SPECIFICATIONS 25-9-3
SPECIAL TORQUES 25-9-3
SPECIAL TOOLS 25-9-3
REMOVAL OF THE FRONT DIFFERENTIAL CARRIER ASSEMBLY 25-9-4
REMOVAL OF THE FRONT DIFFERENTIAL FROM THE CARRIER HOUSING 25-9-5
DISASSEMBLY OF THE DIFFERENTIAL 25-9-7
PINION DISASSEMBLY 25-9-9
ASSEMBLY OF THE DIFFERENTIAL 25-9-12
DIFFERENTIAL CARRIER ASSEMBLY 25-9-16
SETTING THE PINION DEPTH 25-9-18
ADJUSTING BEARING PRELOAD 25-9-21
DIFFERENTIAL INSTALLATION 25-9-23

FWD PLANETARY HUB, STEERING KNUCKLE AND AXLE DRIVE SHAFT .....SECTION 25, CHAPTER 10
SPECIFICATIONS 25-10-3
SPECIAL TORQUES 25-10-3
SPECIAL TOOLS 25-10-3
PLANETARY HUB DISASSEMBLY 25-10-4
STEERING KNUCKLE AND KINGPIN DISASSEMBLY 25-10-9
AXLE DRIVE SHAFT DISASSEMBLY 25-10-13
AXLE SHAFT ASSEMBLY 25-10-14
KINGPIN ASSEMBLY 25-10-16
STEERING KNUCKLE ASSEMBLY 25-10-20
PLANETARY HUB ASSEMBLY 25-10-25
Ten Bolt Axle Only 25-10-30
Twelve Bolt Axle Only 25-10-34
All Axles 25-10-39

SUSPENSION FWD AXLE.....SECTION 25, CHAPTER 11
SPECIAL TORQUES 25-11-2
SUSPENSION FWD AXLE 25-11-3
Disassembly 25-11-3
Assembly 25-11-13
Position Sensor Adjustment 25-11-25

SUPERSTEER AXLE VERTICAL CONTROL LINKAGE .....SECTION 25, CHAPTER 12
SPECIAL TORQUES 25-12-3
VERTICAL LINK DISASSEMBLY AND REPAIR 25-12-3
Vertical Link Removal 25-12-3
Roller Replacement 25-12-4
Articulation Bearing Removal and Installation 25-12-5

REAR AXLE AND PLANETARIES.....SECTION 27, CHAPTER 1
SPECIAL TOOLS 27-1-3
SPECIAL TORQUES 27-1-5
SPECIFICATIONS 27-1-5
GENERAL INFORMATION 27-1-5
REAR AXLE 27-1-6
AXLE HOUSING DISASSEMBLY 27-1-9
PLANETARY DISASSEMBLY 27-1-11
DIFFERENTIAL CARRIER SEAL REPLACEMENT 27-1-13
PLANETARY ASSEMBLY - THREE PIN 27-1-14
PLANETARY ASSEMBLY - FOUR PIN 27-1-15
AXLE HOUSING ASSEMBLY 27-1-18
HOW TO DETERMINE RAM PRESSURE 27-1-23
AXLE INSTALLATION 27-1-26
AXLE SEAL WEAR SLEEVE INSTALLATION (4-Inch Axle Only) 27-1-30

POWER TAKE OFF CONTROL SYSTEM - HOW IT WORKS .....SECTION 31, CHAPTER 1
POWER TAKE OFF 31-1-3
ELECTRONIC PTO CONTROL 31-1-4
PTO SYSTEM CONTROL 31-1-7
PTO CONTROL MODES 31-1-8
PTO VALVE OIL SUPPLY 31-1-10
PTO DIFFERENTIAL LOCK VALVE 31-1-11
TROUBLESHOOTING 31-1-12

PTO CLUTCH ASSEMBLY - SINGLE, REVERSIBLE AND DUAL SPEED ..... SECTION 31, CHAPTER 2
SPECIAL TOOLS 31-2-3
SPECIAL TORQUES 31-2-3
PTO CLUTCH ASSEMBLY 31-2-4
General 31-2-4
PTO CLUTCH SERVICE 31-2-4
Removal 31-2-4
Disassembly 31-2-6
Assembly 31-2-16
Exploded View of PTO Clutch 31-2-16
Cross Section of PTO Clutch and Output Shaft Assembly 31-2-31
SINGLE SPEED REVERSIBLE SHAFT PTO 31-2-32
Disassembly 31-2-32
Assembly 31-2-35
Exploded View of PTO Output Shaft and Driven Gear Assembly 31-2-35
SINGLE SPEED REVERSIBLE SHAFT PTO DRIVEN GEAR 31-2-39
Removal 31-2-39
Assembly 31-2-41
Reversible PTO Output Shaft Bearing Adjustment 31-2-43
SINGLE SPEED REVERSIBLE SHAFT PTO 31-2-45
Cross Section of PTO Output Shaft Assembly 31-2-45

BRAKE VALVE ..... SECTION 33, CHAPTER 1
SPECIAL TORQUES 33-2-2
BRAKE VALVE 33-2-3
Removal 33-2-3
Disassembly 33-2-4
Assembly 33-2-6
Installation 33-2-8

BRAKE CYLINDERS ..... SECTION 33, CHAPTER 2
SPECIAL TORQUES 33-2-3
SPECIFICATIONS 33-2-3
BRAKE CYLINDERS 33-2-3
Disassembly 33-2-3
Assembly 33-2-5

HYDRAULIC SCHEMATIC POSTER - EUROPEAN 87518877

HOW TO READ SYMBOLS IN A HYDRAULIC SCHEMATIC ..... SECTION 35, CHAPTER 1
HOW TO READ SYMBOLS IN A HYDRAULIC SCHEMATIC 35-1-3
SIMPLE SCHEMATIC 35-1-13
COMMON SYMBOLS 35-1-15

HYDRAULIC SYSTEM - HOW IT WORKS WITH TROUBLESHOOTING ..... SECTION 35, CHAPTER 2
GENERAL INTRODUCTION 35-2-3
REAR CHARGE/LUBE PUMP PRESSURE TEST 35-2-19
REGULATED SYSTEM PRESSURE TEST AND ADJUSTMENT PROCEDURE 35-2-21
FRONT/REGULATED SYSTEM PUMP FLOW TEST 35-2-25
STEERING RELIEF PRESSURE TEST AND ADJUSTMENT PROCEDURE 35-2-27
STEERING SYSTEM PROBLEMS 35-2-29
PRIORITY AND REGULATOR VALVE 35-2-31
PFC AXIAL PISTON PUMP 35-2-34
PFC PUMP HIGH PRESSURE STANDBY CHECK AND ADJUSTMENT PROCEDURE 35-2-42
PFC PISTON PUMP FLOW TEST 35-2-43
PFC PISTON PUMP FLOW COMPENSATOR SETTING 35-2-44
STANDARD PUMP COMPENSATOR VALVE INSPECTION 35-2-46
PFC PUMP OPERATIONAL PROBLEMS 35-2-47

PTO AND DIFFERENTIAL LOCK VALVE ..... SECTION 35, CHAPTER 3
SPECIAL TORQUES 35-3-2
SPECIFICATIONS 35-3-2
PTO AND DIFFERENTIAL LOCK VALVE 35-3-3

REMOTE VALVE AND COUPLER SERVICE ..... SECTION 35, CHAPTER 4
SPECIAL TORQUES 35-4-2
REMOTE VALVE AND COUPLER SERVICE 35-4-3
REMOTE VALVE REMOVAL AND SERVICE 35-4-5
REMOTE COUPLERS 35-4-13

REMOTE HYDRAULIC SYSTEM - HOW IT WORKS AND TROUBLESHOOTING ..... SECTION 35, CHAPTER 5
REMOTE HYDRAULIC SYSTEM INTRODUCTION 35-5-3
REMOTE VALVE SYSTEM COMPONENTS 35-5-5
REMOTE VALVE SYSTEM CONTROLS 35-5-10
REMOTE VALVE OPERATION 35-5-14
REMOTE VALVE PROBLEMS AND WHERE TO LOOK 35-5-23
REMOTE VALVE PROPORTIONAL CURRENT CONTROL (PCC) SOLENOID OPERATION 35-5-25
REMOTE VALVE SYSTEM TESTING 35-5-26
REMOTE VALVE HIGH PRESSURE TEST 35-5-27
PFC PUMP HIGH PRESSURE STANDBY CHECK AND ADJUSTMENT PROCEDURE 35-5-28
PFC PISTON PUMP FLOW TEST 35-5-29
STANDARD PUMP COMPENSATOR VALVE INSPECTION 35-5-30
REMOTE VALVE SIGNAL CHECK AND HITCH SIGNAL CHECK 35-5-31
REMOTE VALVE COUPLER TEST 35-5-32
LOAD CHECK INSPECTION 35-5-33
OPERATIONAL PROBLEMS 35-5-34

PRIORITY AND REGULATOR VALVE ..... SECTION 35, CHAPTER 6
SPECIAL TORQUES 35-6-3
PRIORITY VALVE AND REGULATOR 35-6-4
Removal 35-6-4
Disassembly 35-6-6
Assembly 35-6-9
Installation 35-6-12
CROSS SECTION OF PRIORITY AND REGULATOR VALVE 35-6-14

CHARGE PUMP ..... SECTION 35, CHAPTER 7
Removal 35-7-3
Installation 35-7-4

PFC PISTON PUMP AND HYDRAULIC FILTER ..... SECTION 35, CHAPTER 8
SPECIAL TORQUES 35-8-3
PFC PISTON PUMP 35-8-3
Removal 35-8-3
Installation 35-8-4

HITCH SYSTEM - HOW IT WORKS ..... SECTION 35, CHAPTER 9
THREE POINT HITCH 35-9-3
ELECTRONIC HITCH CONTROL 35-9-4
ELECTRONIC HITCH CONTROL SYSTEM FEATURES 35-9-7
HITCH CONTROL VALVE 35-9-14
SETUP / ADJUSTMENT SEQUENCE 35-9-22

HITCH CONTROL VALVE ..... SECTION 35, CHAPTER 10
HITCH CONTROL VALVE 35-10-3
Removal 35-10-3
Disassembly 35-10-5
Assembly 35-10-7
Installation 35-10-9
HITCH CONTROL VALVE CROSS SECTION 35-10-11

TRACTOR HITCH ..... SECTION 35, CHAPTER 11
SPECIAL TORQUES 35-11-3
TRACTOR HITCH 35-11-3
EDC PIN ASSEMBLY 35-11-20
POTENTIOMETER (HITCH POSITION SENSOR) 35-11-21
CAM SWAY LIMITER 35-11-23
CAM BUMPERS FOR DRAFT ARM 35-11-25
DRAWBAR, HIGH VERTICAL CAPACITY 35-11-26

STEERING COLUMN AND STEERING HAND PUMP ..... SECTION 41, CHAPTER 1
SPECIAL TOOLS 41-1-2
SPECIAL TORQUES 41-1-3
STEERING COLUMN REMOVAL 41-1-3
STEERING HAND PUMP SERVICE 41-1-6
STEERING COLUMN ASSEMBLY 41-1-8

WHEEL TOE IN SETTING SUPERSTEER FWD AXLE ..... SECTION 41, CHAPTER 2
WHEEL TOE IN SETTING 41-2-3
WHEEL TOE IN SETTING DIAGRAM 41-2-9
SPECIAL TOOL LAYOUT DRAWINGS 41-2-10

A/C TROUBLESHOOTING ..... SECTION 50, CHAPTER 1
SAFETY PROCEDURES 50-1-5
SPECIAL TOOLS 50-1-6
A/C THERMAL OPERATION 50-1-7
A/C SYSTEM COMPONENTS 50-1-9
Cab HVAC Box Components - Automatic Temperature Control 50-1-9
Chassis Components 50-1-11
AUTOMATIC TEMPERATURE CONTROL (ATC) OPERATION 50-1-12
Operation Modes 50-1-15
Automatic Mode 50-1-15
Defog Mode 50-1-15
Automatic Operation Summary 50-1-16
Defog/Dehumidify Operation Summary 50-1-17
ATC Fault Codes 50-1-18
ATC Fault Code 111 50-1-18
ATC Fault Code 112 50-1-19
ATC Fault Code 115 50-1-19
ATC Fault Code 116 50-1-20
ATC Fault Code 120 50-1-20
ATC Fault Code 121 50-1-21
ATC Fault Code 122 50-1-21
ATC Fault Code 125 50-1-22
ATC Fault Code 126 50-1-22
ATC Fault Code 127 50-1-23
ATC Fault Code 128 50-1-23
ATC Fault Code 129 50-1-24
ATC Fault Code 130 50-1-24
ATC Fault Code 131 50-1-25
ATC Fault Code 132 50-1-25
ATC Fault Code 133 50-1-26
ATC Fault Code 134 50-1-26
Locating System Problems Without Fault Codes 50-1-27
Controller-Based Resistance Tests 50-1-27
ATC Controller Test (Connector J8 Test Points) 50-1-29
ATC Field Reported Symptoms/Causes 50-1-32
Compressor And Clutch 50-1-33
Operational Check 50-1-33
Electrical Test 50-1-36
Compressor Clutch Control Circuit Test Procedure 50-1-36
Service Note: Adjusting Clutch Air Gap 50-1-38
High And Low Pressure Switch Clutch Latching Circuit 50-1-39
Background 50-1-39
Possible Failure Modes - Fault Codes 129 and 134 50-1-40
Electrical Test 50-1-41
High Pressure Switch and Circuit Test 50-1-41
Low Pressure Switch and Circuit Test 50-1-42
Heater Control Valve 50-1-43
Operational Check 50-1-43
Electrical Test 50-1-44
Heater Control Valve Power, Signal and Ground Test 50-1-44
Blower Speed And Temperature Control Potentiometers 50-1-45
Background 50-1-45
Possible Failure Modes - Fault Codes 120, 121 50-1-45
Electrical Test 50-1-46
Common Control Potentiometer and Circuit Test Procedure 50-1-46

BLOWER AND BLOWER SPEED DRIVER 50-1-47
Background 50-1-47
Power, Signal and Ground Circuit 50-1-47
Possible Failure Modes 50-1-47
Blower Motor/Blower Driver Power, Signal and Ground Test 50-1-48
Cab And Evapator Temperature Sensors 50-1-49
Background 50-1-49
Electrical Test 50-1-51
Power Circuit 50-1-51
Possible Failure Modes - Fault Codes 111, 115 and 116 50-1-52
Cab Temperature Sensor and Circuit Test 50-1-53
Evaporator Temperature Sensor and Circuit Test 50-1-54
Controller Power, Ground, And ATC Switch 50-1-56
Background 50-1-56
Power and Ground Circuit 50-1-56
Possible Failure Modes 50-1-56
Controller Power Supply and Ground Test 50-1-56
ATC Switch and Circuit Test 50-1-57
Defog/Defrost Switch and Circuit Test 50-1-57
Cab Pressurizer Blower 50-1-58
Background 50-1-58
Power and Ground 50-1-58
Cab Pressurizer Blower & Relay Power Supply and Ground Test 50-1-58
ACCESSING THE HVAC BOX 50-1-59
STANDARD AIR CONDITIONING (STD) TROUBLESHOOTING 50-1-60
Standard A/C Operation 50-1-61
Smart Pressure Switch Cycling System 50-1-61
Standard A/C Controls and Their Function 50-1-62
Symptom-Based Standard A/C Troubleshooting 50-1-63
Standard Controller Test 50-1-65
Compressor And Clutch 50-1-67
Operational Check 50-1-67
Electrical Test – Compressor Clutch 50-1-70
Clutch Relay Power Supply and Ground Test 50-1-71
Service Note: Adjusting Clutch Air Gap 50-1-72
High And Low Pressure Switch Clutch Latching Circuit 50-1-73
Background 50-1-73
Possible Failure Modes - Flashing Pressure Warning Lamp 50-1-74
Electrical Test – Pressure Switches 50-1-75
High Pressure Switch and Circuit Test 50-1-75
Low Pressure Switch and Circuit Test 50-1-76
Heater Control Valve 50-1-77
Operational Check 50-1-77
Electrical Test 50-1-78
Temperature Control Potentiometer 50-1-79
Background 50-1-79
Electrical Test 50-1-79
Blower Speed Switch And Blower Motor 50-1-80
Background 50-1-80
Power and Ground Circuit 50-1-80
Possible Failure Modes 50-1-80
Blower Speed Switch and Power Circuit Test 50-1-81
Blower Motor Power, and Control Circuit Test 50-1-81

Evaporator Temperature Sensor 50-1-83
Background 50-1-83
Electrical Test – Sensor 50-1-83
Power Circuit 50-1-84
Service Note: Too Little Cooling/Too Much Heating without Symptoms 50-1-84
Evaporator Temperature Sensor and Circuit Test 50-1-84
Controller Power, Ground And A/C Switch 50-1-86
Background 50-1-86
Power and Ground Circuit 50-1-86
Possible Failure Modes 50-1-86
Controller Power Supply and Ground Test 50-1-86
A/C Switch and Circuit Test 50-1-87
Cab Pressurizer Blower 50-1-88
Background 50-1-88
Power and Ground 50-1-88
Cab Pressurizer Blower & Relay Power Supply and Ground Test 50-1-89

AIR CONDITIONER SYSTEM SERVICE ..... SECTION 50, CHAPTER 2
SPECIFICATIONS 50-2-4
SPECIAL TORQUES 50-2-4
SPECIAL TOOLS 50-2-4
SAFETY PROCEDURES 50-2-9
AIR CONDITIONER SYSTEM REFRIGERANT RECOVERY 50-2-10
RECOVERING PURE 134A REFRIGERANT 50-2-12
RECOVERING CONTAMINATED REFRIGERANT WITH OEM1691 50-2-16
Preparing the Tank 50-2-16
Recovery Process 50-2-20
AIR CONDITIONER SYSTEM EVACUATION AND RECHARGING 50-2-26
AIR CONDITIONING TEMPERATURE/PRESSURE CHART 50-2-33
A/C SYSTEM FLUSHING PROCEDURE 50-2-34
Required Tools 50-2-35
Precautions 50-2-36
Component Flushing Procedure with Power Flush 17550 50-2-37
Complete Circuit Flushing Procedure with Power Flush 17550 50-2-41
Back Flushing the Thermal Expansion Valve or Refrigerant Line 50-2-46
Post Flushing Procedures 50-2-48
Flushing Solvent Disposal 50-2-50
LEAK DETECTION 50-2-51
Electronic Testing with OEM1437 50-2-52
Fluorescent Leak Detection 50-2-53
Fluorescent Dye Injection 50-2-53
Fluorescent Leak Testing 50-2-59
A/C SYSTEM COMPONENTS 50-2-60
Cab HVAC Box Components - Automatic Temperature Control 50-2-60
Cab HVAC Components - Standard Systems 50-2-62
Chassis Components 50-2-64
A/C COMPRESSOR CLUTCH 50-2-65
Clutch Removal 50-2-65
Exploded View of Clutch 50-2-71
Compressor Clutch Replacement 50-2-71
A/C COMPRESSOR 50-2-79
Oil Level Check or Adjustment 50-2-79
Compressor Removal 50-2-82
Compressor Installation 50-2-85
CONDENSER AND RECEIVER-DRIER 50-2-87
Condenser 50-2-87
Receiver-Drier 50-2-88
ACCESSING THE HVAC BOX 50-2-90
THERMAL EXPANSION VALVE TESTING 50-2-92
THERMAL EXPANSION VALVE REPLACEMENT 50-2-93
EVAPORATOR AND CAB TEMPERATURE SENSOR LOCATION 50-2-95
BLOWER MOTOR REPLACEMENT 50-2-96
HEATER CONTROL VALVE REPLACEMENT 50-2-97
EVAPORATOR/HEATER ASSEMBLY 50-2-98
Evaporator/Heater Assembly Removal 50-2-98
Evaporator/Heater Assembly Installation 50-2-101
Post Replacement Procedures 50-2-104
EVAPORATOR/HEATER ASSEMBLY SEALING AND CLEANING 50-2-105
BLOWER AND EVAPORATOR REFERENCE ILLUSTRATION 50-2-106
CONTROLLER AND BLOWER SPEED DRIVER REPLACEMENT 50-2-107
ATC Controller 50-2-107
Standard A/C Controller 50-2-107
Blower Speed Driver (ATC Units Only) 50-2-108
CAB AIR FILTER SERVICE 50-2-109

Click on the image link below for the full version of the service manual

