YANMAR

SERVICE MANUAL

EXCAVATOR

MODEL SV100

CONTENTS

CHAPTER 1
GENERAL CAUTIONS FOR MAINTENANCE WORK

1-1 Correct Work 1-1
1-2 Safety Precautions 1-1
1-3 Preparations 1-1
1-4 Cautions for Disassembly and Reassembly 1-1
1-5 Cautions for Removal and Installation of Hydraulic Equipment 1-2
1-6 Cautions for Removal and Installation of Hydraulic Piping 1-2
1-7 Cautions for Handling Seals 1-3
1-8 Correct Installation of Hydraulic Hose 1-3
1-9 Specifications of Hydraulic Hose 1-6
1-10 Air Release of Hydraulic Equipment 1-11

CHAPTER 2
TECHNICAL DATA

2-1 Specifications 2-1-1
2-2 Outline Drawing and Working Area 2-2-1
2-2-1 Quick coupler 2-2-1
2-2-2 W/O Quick coupler 2-2-2
2-3 Weight List of Main Parts 2-3-1
2-4 Lifting Capacity List 2-4-1
2-4-1 SV100 2-4-1

CHAPTER 3
SERVICE STANDARDS

3-1 Machine Performance 3-1-1
3-2 Engine 3-2-1
3-3 Undercarriage 3-3-1
3-3-1 Rubber Crawler Specifications 3-3-1
3-3-2 Steel Crawler Specifications 3-3-2
3-3-3 Common Specifications of Steel & Rubber Crawlers 3-3-3
3-4 Controls 3-4-1
3-5 Hydraulic Equipment 3-5-1
3-5-1 Hydraulic Cylinders 3-5-1
3-6 Implement 3-6-1
3-6-1 Front Attachments (Quick Coupler Type) 3-6-1
3-6-2 Blade Moving Device 3-6-2
3-6-3 Bucket Teeth 3-6-2
3-7 List of Tightening Torque 3-7-1
3-7-1 Machine 3-7-1
3-7-2 Engine 3-7-4
3-7-3 Tightening Torque for General Bolts and Nuts 3-7-4

CHAPTER 4
ENGINE

4-1 General 4-1-1
4-1-1 How to Read This Manual 4-1-1
4-1-2 Precautions for Service Work 4-1-3
4-1-3 Engine External Views 4-1-4
4-1-4 Structural Description 4-1-4
4-1-5 Exhaust Gas Emission Regulation 4-1-5
4-2 Troubleshooting 4-2-1
4-2-1 Quick Reference Table for Troubleshooting 4-2-1
4-2-2 Troubleshooting by Measuring Compression Pressure 4-2-4
4-3 Inspection and Adjustment 4-3-1
4-3-1 Oil Inspection 4-3-1
4-3-2 Cooling Water Inspection 4-3-1
4-3-3 Inspecting Water Leak from Cooling Water System and Radiator 4-3-1
4-3-4 Fan Belt Tension Inspection and Adjustment 4-3-2
4-3-5 Adjusting the Valve Clearance 4-3-3
4-3-6 Inspecting the Fuel Injection Valve Injection Pressure and Spray Pattern 4-3-5
4-3-7 Fuel Injection Timing Adjustment / Fuel Injection Pump Inspection and Adjustment 4-3-9
4-3-8 Sensor Inspection 4-3-12
4-3-9 Battery Inspection 4-3-13
4-3-10 Adjusting Operation 4-3-15
4-3-11 Long Storage 4-3-16
4-3-12 Periodic Maintenance Schedule 4-3-17
4-4 Engine Body 4-4-1
4-4-1 Introduction 4-4-1
4-4-2 Cylinder Head 4-4-2
4-4-3 Gear Train and Camshaft 4-4-10
4-4-4 Cylinder Block 4-4-15
4-5 Lubrication System 4-5-1
4-5-1 Lubrication System Diagram 4-5-1
4-5-2 Trochoid Pump Components 4-5-1
4-5-3 Disassembly (Reverse the Procedure Below for Assembly) 4-5-2
4-5-4 Servicing Points 4-5-2
4-5-5 Parts Inspection and Measurement 4-5-2
4-6 Cooling System 4-6-1
4-6-1 Cooling Water System 4-6-1
4-6-2 Cooling Water Pump Components 4-6-1
4-6-3 Disassembly (Reverse the Procedure Below for Assembly) 4-6-2
4-6-4 Servicing Points 4-6-2
4-7 Fuel Injection Pump / Governor 4-7-1
4-7-1 Introduction 4-7-1
4-7-2 Fuel Injection Pump 4-7-1

4-8 Turbocharger : Disassembly, Inspection and Reassembly 4-8-1
4-8-1 Structure and Functions 4-8-1
4-8-2 Service Standards and Tightening Torque 4-8-4
4-8-3 Periodic Inspection Procedure 4-8-5
4-8-4 Disassembly Procedure 4-8-9
4-8-5 Washing and Inspection procedure 4-8-12
4-8-6 Reassembly Procedure 4-8-16
4-8-7 Handling after Disassembly and Reassembly 4-8-19
4-8-8 Troubleshooting 4-8-20
4-9 Starting motor 4-9-1
4-9-1 Specifications 4-9-1
4-9-2 Configuration Drawing 4-9-2
4-9-3 Troubleshooting 4-9-3
4-9-4 Component Names and Disassembly Procedure 4-9-4
4-9-5 Disassembly Procedure 4-9-5
4-9-6 Inspection and Maintenance 4-9-7
4-9-7 Assembly 4-9-11
4-9-8 Adjustment 4-9-12
4-9-9 Service Standards 4-9-13
4-10 Alternator 4-10-1
4-10-1 Specifications 4-10-1
4-10-2 Section View 4-10-2
4-10-3 Troubleshooting 4-10-3
4-10-4 Parts Names and Disassembly Procedure 4-10-4
4-10-5 Inspection and Overhaul 4-10-7
4-10-6 Assembly 4-10-11
4-10-7 Service Standards 4-10-12
4-10-8 Performance Test 4-10-13
4-11 Special Service Tools 4-11-1
4-11-1 Special Tools 4-11-1
4-11-2 Measuring Instruments 4-11-3
4-12 Service Standards 4-12-1
4-12-1 Engine Turning 4-12-1
4-12-2 Engine Body 4-12-2
4-12-3 Lubricating Oil System (Trochoid Pump) 4-12-6
4-12-4 Tightening Torques for Main Parts 4-12-7

CHAPTER 5
HYDRAULIC SYSTEM

5-1 Outline (Quick Coupler Type) 5-1-1
5-1-1 Control Valve Operation 5-1-3
5-1-2 Additional Operation of Control Valve 5-1-4
5-2 Hydraulic Circuit Schematic 5-2-1

5-3 Circuit Operation 5-3-1
5-3-1 Boom 5-3-1
5-3-2 Arm 5-3-2
5-3-3 Bucket 5-3-3
5-3-4 Swing 5-3-4
5-3-5 Boom Swing 5-3-5
5-3-6 Blade 5-3-6
5-3-7 Travel 5-3-7
5-3-8 Non-deviation Travel (with Boom, Arm, Bucket or Boom Swing Operation) 5-3-8
5-3-9 Simultaneous Operation of Boom Up and Arm Retract 5-3-9
5-3-10 Simultaneous Operation of Boom Up and Bucket 5-3-10
5-3-11 Simultaneous Operation of Boom Up and Swing 5-3-11
5-3-12 Simultaneous Operation of Arm and Bucket 5-3-12
5-3-13 Hydraulic P.T.O. 5-3-13
5-3-14 Travel Alarm 5-3-14
5-3-15 Quick Coupler 5-3-15
5-3-16 2nd P.T.O. 5-3-16
5-4 Pressure Adjustment 5-4-1
5-4-1 Relief Valves 5-4-1
5-4-2 Swing Brake Valve 5-4-3
5-4-3 Cut-off Valve 5-4-4

CHAPTER 6
HYDRAULIC EQUIPMENT

6-1 Hydraulic Pump 6-1-1
6-2 Control Valve 6-2-1
6-2-1 Hydraulic Circuit Schematic and Parts Name 6-2-1
6-2-2 Operation of Each Spool Section 6-2-2
6-2-3 Relief Valves 6-2-27
6-3 Pilot Valve 6-3-1
6-4 Swing Motor 6-4-1
6-5 Travel Motor 6-5-1
6-5-1 Specifications 6-5-1
6-5-2 Model Labeling 6-5-1
6-5-3 External Dimensions 6-5-2
6-5-4 Basic Configuration and Drawing 6-5-3
6-5-5 Operating Description 6-5-6
6-5-6 Troubleshooting 6-5-12
6-5-7 Disassembly 6-5-14
6-5-8 Service Preparations 6-5-31
6-5-9 Assembly 6-5-33
6-5-10 Performance Congirmation Test 6-5-48
6-5-11 Clearance Adjustment Parts Dimensions Table 6-5-49
6-6 Pilot Check Valve (Quick Coupler Type) 6-6-1

CHAPTER 7
ADJUSTMENT AND REPAIR

7-1 Electric Equipment of the Machine 7-1-1
7-1-1 Parts Layout of Electrical Equipment 7-1-1
7-1-2 Monitor and Alarm Systems 7-1-4
7-1-3 Wiring Diagram 7-1-7
7-1-4 Stop Motor Operation 7-1-9
7-1-5 Removal and Reinstallation of Engine 7-1-11
7-1-6 Removal and Reinstallation of Starter Motor 7-1-21
7-1-7 Removal and Reinstallation of Radiator 7-1-22
7-1-8 Removal and Reinstallation of Fan Belt and Compressor Driving Belt 7-1-25
7-1-9 Removal and Reinstallation of Fuel Injection Pump 7-1-26
7-2 Undercarriage 7-2-1
7-2-1 Outline 7-2-1
7-2-2 Compatibility of Main Parts 7-2-1
7-2-3 Points of Reassembly (Rubber Crawler Type) 7-2-2
7-2-4 Points of Reassembly (Steel Crawler Type) 7-2-3
7-2-5 Removal and Reinstallation of Crawler 7-2-4
7-2-6 Disassembly and Reassembly of Steel Crawler 7-2-7
7-2-7 Disassembly and Reassembly of Front Idler 7-2-9
7-2-8 Disassembly and Reassembly of Track Roller 7-2-11
7-2-9 Installation of Floating Seal 7-2-13
7-2-10 Disassembly and Reassembly of Carrier Roller 7-2-14
7-3 Controls 7-3-1
7-3-1 Control Train 7-3-1
7-3-2 Mechanical Control Linkage 7-3-2
7-3-3 Adjustment of Travel Levers 7-3-4
7-3-4 Adjustment of Boom Swing Pedal 7-3-5
7-3-5 Adjustment of Blade Lever 7-3-5
7-3-6 Adjustment of Lock Lever 7-3-6
7-3-7 Adjustment Procedure of P.T.O. Pedal 7-3-7
7-3-8 Adjustment Procedure of P.T.O. Pedal Lock 7-3-7
7-3-9 Adjustment of Accelerator Lever 7-3-8
7-4 Swing Bearing 7-4-1
7-4-1 Removal and Reinstallation of Swing Bearing 7-4-1
7-5 Hydraulic Equipment 7-5-1
7-5-1 Removal and Reinstallation of Hydraulic Pump 7-5-1
7-5-2 Removal and Reinstallation of Control Valve 7-5-5
7-5-3 Removal and Reinstallation of Swing Motor 7-5-8
7-5-4 Removal and Reinstallation of Swivel Joint 7-5-10
7-5-5 Disassembly and Reassembly of Swivel Joint 7-5-13
7-5-6 Disassembly and Reassembly of Hydraulic Cylinders 7-5-16
7-5-7 Hydraulic Oil Tank 7-5-20
7-5-8 Piping Layout 7-5-26

7-6 Implement 7-6-1
7-6-1 Removal and Reinstallation of Implement 7-6-1
7-6-2 Quick Coupler 7-6-9
7-7 Air Conditioner 7-7-1
7-7-1 Removal and Reinstallation of Air Conditioner 7-7-1

CHAPTER 8
PERIODIC INSPECTION AND SERVICING

8-1 List of Periodic Inspection and Servicing 8-1

CHAPTER 9
FUEL, LUBE OIL AND GREASE RECOMMENDED

9. Fuel, Lube Oil and Grease Recommended 9-1

CHAPTER 10
TROUBLESHOOTING

10-1 Non-breakdowns 10-1-1
10-1-1 Natural Release of Bucket 10-1-1
10-1-2 Discontinuous Arm Movement 10-1-1
10-1-3 Thermal Shock of Travel Motor 10-1-2
10-1-4 Elongation of Boom Swing Cylinder on 68 degrees Swing 10-1-3
10-1-5 Time Lag on Travel Speed Switching 10-1-4
10-1-6 Fluctuation in Oil Level of Hydraulic Oil Tank due to Temperature Change 10-1-5
10-1-7 Operation of Quick Coupler Cylinder 10-1-6
10-2 Troubleshooting 10-2-1
10-2-1 Machine and Engine 10-2-1
10-2-2 Electrical Equipment on Panel 10-2-23

CHAPTER 11
REFERENCE DATA

11-1 Specifications for Attachment 11-1

