TZ18DA, TZ22DA, TZ24DA, TZ25DA REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION 2

SECTION 10 - ENGINE SYSTEMS 4

SECTION 25 - FWD 11

SECTION 27 - DIFFERENTIAL AND REAR AXLES 13

SECTION 29 - HYDROSTATIC TRANSMISSION 14

SECTION 31 - PTO 17

SECTION 33 - BRAKES 19

SECTION 35 - HYDRAULIC SYSTEM 19

SECTION 41 - POWER STEERING 23

SECTION 44 - WHEELS 25

SECTION 55 - ELECTRICAL SYSTEM 26

SECTION 58 - 54CMS-60CMS MID MOUNT MOWER 35

SECTION 90 - PLATFORM 36

The following pages are the collation of the contents pages from each section and chapter of the TZ18DA, TZ22DA, TZ24DA, TZ25DA Repair manual. Complete Repair part # 87350100.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TZ18DA, TZ22DA, TZ24DA, TZ25DA Tractors.

© 2005 CNH America LLC
Printed In U.S.A.

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87350101

Chapter 1 - General Information

CONTENTS

Section	Description	Page
	Precautionary Statements	3
	Personal Safety	3
	Machine Safety	3
	Information	3
	Safety	4
	Precautionary Statements	4
	The Tractor	4
	Servicing the Tractor	4
	Operating the Tractor	5
	Driving the Tractor	5
	Operating the PTO	6
	Diesel Fuel	6
	Safety Frame (ROPS)	6
	Safety Decals	7
	Instruction Decals	10
	Ecology and the Environment	16
	Helpful Hints	16
	Universal Symbols	17
	General Information	18
	Please Read Carefully	18
	Minimum Hardware Tightening Torques	19
	Metric Bolt Torque Specifications	20
	Lubrication and Maintenance	21
	General Information	21
	Grease Fittings	21
	Chains	21
	Lubrication and Maintenance Chart	23
	Lubrication Fittings	24
	Diesel Fuel	24
	Fuel Usage Safety	24

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87350101

Chapter 1 - General Information (Continued)

CONTENTS

Section	Description	Page
	Specifications	25
	Engine	25
	Capacities	25
	Cooling System	26
	Electrical System	26
	Fuel System	26
	Brakes	27
	Steering	27
	Power Take-Off (PTO)	27
	Hydraulic Lift Section	27
	Transmission Speeds	28
	Cast Iron Weights	29
	Drawbars	29
	3-Point Hitch	29
	Tires	29
	Wheel Bolt Torques	29
	ROPS Attaching Bolt Torques	29
	General Dimensions	30
	Wheel Tread Settings	30
	Liquid Ballast (optional)	32
	Tire Pressure	32

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87350101

Chapter 1 - Engine Systems

CONTENTS

Section	Description	Page
10 000	Specifications	6
	Torque Specifications	15
	Metric Bolt Torque Specifications	15
	Special Tools	16
	General Information – Description of Operation	17
	Identification Chart	17
	Cylinder Head and Valve Train Components	17
	Cylinder Block Assembly	19
	Troubleshooting	20
	Overhaul	26
	Engine Access	26
	Disassembly	26
	Fuel Injector and Glow Plug	29
	Removal	29
	Hydraulic Pump	30
	Removal	30
	Fan, Water Pump and External Oil Tube	30
	Removal	30
	Fuel Shutoff Solenoid	30
	Removal	30
	Oil Pressure Switch	31
	Removal	31
	Temperature Sending Switch and Alternator	31
	Removal	31
	Throttle Cable	31
	Disconnection	31
	Support Frame	32
	Removal	32
	Engine	32
	Removal	32
	Valve Cover	33
	Removal	33

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87350101

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Rocker Shaft and Push Rod	34
	Removal	34
	Cylinder Head	34
	Removal	34
	Valve Tappet	35
	Removal	35
	Engine Timing Gear Cover, Timing Gears and Camshaft	35
	Timing Gears and Camshaft	36
	Removal	36
	Oil Sump	36
	Removal	36
	Oil Suction Pipe and Strainer	37
	Removal	37
	Connecting Rods, Bearings and Piston	37
	Removal	37
	Flywheel	38
	Removal	38
	Backplate and Oil Seal	38
	Removal	38
	Crankshaft and Main Bearings	38
	Removal	38
18 110	Cylinder Head	39
	Disassembly	39
	Inspection and Repair	39
	Valve Seats	40
	Inspection and Repair	40
	Valves	40
	Inspection and Repair	40
	Valve Guides	42
	Inspection and Repair	42
	Valve Springs	42
	Inspection and Repair	42

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87350101

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Rocker Arms	43
	Inspection and Replacement	43
	Push Rods	43
	Inspection and Replacement	43
	Cylinder Head	44
	Assembly	44
	Cylinder Block	44
	Inspection and Repair	44
10 105	Pistons	45
	Disassembly and Inspection	45
	Piston Rings	47
	Inspection and Replacement	47
	Connecting Rods	48
	Inspection and Repair	48
	Connecting Rod Bearing Oil Clearance Check	50
	Pistons, Rings and Connecting Rod	50
	Assembly	50
10 103	Main Bearing and Thrust Bearing	51
	Removal and Inspection	51
	Crankshaft	52
	Inspection	52
	Crankshaft Journal Wear Limit and Bearing Usage	52
	Crankshaft Front Main Bearing (Bushing)	53
	Inspection	53
	Replacement	53
	Crankshaft Main Bearing	54
	Assembly	54
	Port Block	54
	Removal	54
	Installation	55
	Timing Gear	55
	Inspection	55

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87350101

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Camshaft	55
	Disassembly	55
	Inspection	56
	Assembly	56
10 103	Flywheel	57
	Inspection	57
	Timing Gear Housing	57
	Front Oil Seal and Steering Pump Seal	57
	Replacement	57
	Crankshaft and Bearing Holder	58
	Assembly	58
	Rear Oil Seal and Backplate	58
	Assembly	58
	Flywheel	59
	Installation	59
	Piston and Connecting Rod	59
	Installation	59
	Oil Suction Pipe and Suction Strainer	60
	Installation	60
	Oil Sump	60
	Installation	60
	Timing Gear Cover, Timing Gears and Camshaft	60
	Assembly	60
	Head Gasket Selection	62
	Cylinder Head	63
	Assembly	63
	Valve Clearance Adjustment	64
	Valve Cover	64
	Installation	64
	Engine	65
	Installation	65

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87350101

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Drive Train	66
	Installation	66
	Support Frame	66
	Installation	66
	Tachometer and Throttle Cables	66
	Installation	66
	Alternator and Temperature Sending Switch	67
	Installation	67
	Oil Pressure Switch	67
	Installation	67
	Fuel Shutoff Solenoid	67
	Installation	67
	Fan, Water Pump and External Oil Tube	68
	Installation	68
	Hydraulic Pump	68
	Installation	68
	Glow Plug and Connector	68
	Installation	68
	Fuel Injection Pump	69
	Installation	69
	Fuel Injector	70
	Installation	70
	Fuel Line	70
	Installation	70
	Exhaust Manifold, Air Cleaner and Radiator	71
	Installation	71
10 304	Engine Lubrication System – Description of Operation	74
10 206	Engine Oil Filter	77
	Construction and Function	77
	Maintenance	77
10 304	Oil Pump	77
	Removal	77
	Inspection	77

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87350101

Chapter 1 - Engine Systems (Continued)

CONTENTS

Section	Description	Page
	Installation and Adjustment	78
	Engine Oil Pressure Check	79
	Oil Pressure Relief Valve	79
	Removal	79
	Installation	79
	Oil Consumption	80
10 400	Cooling System – Description of Operation	81
	Maintenance	83
	Coolant	83
	Thermostat	83
	Water Pump	83
	Cooling Fan	83
	Radiator	83
	Radiator Cap	83
10 406	Cooling System Overhaul	84
	Radiator	84
	Removal	84
	Inspection and Repair	85
	Installation	86
10 402	Water Pump and Thermostat	87
	Removal	87
	Inspection and Repair	89
	Installation	90
	Testing	93
	Compression Test and Tools	93

SECTION 10 - ENGINE SYSTEMS

BOOK 1 - 87350101

Chapter 2 - Fuel System

CONTENTS

Section	Description	Page
	Specifications	2
	Torque Specifications	2
	Special Tools	2
	Fuel System – Description of Operation	3
10 242	Injection Pump – Description of Operation	5
10 236	Pumping Elements	7
10 214	Delivery Valves	9
	Troubleshooting – General	11
	Troubleshooting – Fuel Injectors	14
	Troubleshooting – Governor	15
	Troubleshooting – Engine Breather Valve	16
	Overhaul	17
10 214	Injection Pump	17
	Removal	17
	Repair	17
	Installation	17
10 230	Timing and Governor Adjustments	18
	Using Original Pump and Drive Components	18
	New Pump or Drive Component	18
	Installation	18
	Spill-Timing Procedure	19
	Bleeding the Fuel System	23
	Full Screw High Idle Adjustment	23
10 230	Governor – Description of Operation	24
	Governor	26
	Disassembly	26
	Assembly	27
	Adjustments	28
10 218	Injectors – Description of Operation	29
	Injector	30
	Removal	30
	Disassembly	31
	Assembly and Adjustment	31
	Engine Breather Valve	32
	Removal	33
	Installation	33

SECTION 25 - FWD

BOOK 1 - 87350101

Chapter 1 - Front Axle

CONTENTS

Section	Description	Page
	Front Wheel Drive Axle – Description of Operation	3
	FWD	4
	Manual	4
	Auto	4
	Auto Position (Engaged)	5
	Auto Position (Disengaged)	5
	Full Time FWD (Locked Down)	5
	Power Flow	6
	Front Axle	6
	Overhaul	7
	FWD Axle	7
	Removal	7
	Final Drive Case Cover	9
	Removal	9
	Steering Cylinder	9
	Removal	9
	Final Drive Case	9
	Removal	9
	Idler Case	10
	Removal	10
	Idler Case	10
	Disassembly	10
	Differential	10
	Removal	10
	Drive Pinion	11
	Removal	11
	Differential	11
	Disassembly	11
	Inspection	11
	Assembly	11

SECTION 25 - FWD

BOOK 1 - 87350101

Chapter 1 - Front Axle (Continued)

CONTENTS

Section	Description	Page
	Drive Pinion	12
	Installation	12
	Differential	12
	Installation	12
	Backlash Adjustment	13
	Idler Case	15
	Assembly	15
	Axle Seal Installation	15
	Installation	16
	FWD Box	17
	Removal (Manual and Auto)	17
	Manual FWD Box	17
	Disassembly	17
	Inspection	18
	Assembly	18
	Auto FWD Box	20
	Disassembly	20
	Inspection	21
	Assembly	22
	Two Way Clutch (Sensitrack™)	25
	Disassembly	25
	Inspection	25
	Assembly	26
	Front to Rear Axle Ratio	27
	Specifications	29
	Front Wheel Drive	29

SECTION 27 - DIFFERENTIAL AND REAR AXLES

BOOK 1 - 87350101

Chapter 1 - Differential

CONTENTS

Section	Description	Page
	Specifications	2
	Bolt Torque Specifications	3
	Metric Bolt Torque Specifications	3
	Special Tool	3
	Description of Operation	4
27 110	Differential	5
27 110	Differential Lock	6
27 126	Rear Axle	7
	Overhaul	8
27 106	Differential	8
	Removal	8
	Drive Pinion	11
	Removal	11
	Differential	12
	Disassembly	12
	Inspection	14
	Assembly	14
	Ring Gear and Pinion Gear Pattern Specification and Adjustment	18

SECTION 27 - DIFFERENTIAL AND REAR AXLES

BOOK 1 - 87350101

Chapter 2 - Rear Axles

CONTENTS

Section	Description	Page
	Overhaul	2
27 126	Rear Axle	2
	Disassembly	2
	Inspection	2
	Assembly	3

SECTION 33 - BRAKES

BOOK 2 - 87350102

Chapter 1 - Brakes

CONTENTS

Section	Description	Page
	Specifications	2
	Metric Bolt Torque Specifications	3
33 120	Description of Operation	4
	Brakes	5
33 110	Parking Brake	7
	Troubleshooting	8
	Overhaul	9
33 120	Brakes	9
	Removal	9
	Disassembly	9
	Inspection	11
	Assembly	12
	Installation	14
	Adjustments	15
	Brake	15
33 110	Parking Brake	16

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 87350102

Chapter 1 - Hydraulics

CONTENTS

Section	Description	Page
	Specifications	4
	Metric Bolt Torque Specifications	5
	Special Tools	6
	Description and Operation – Hydraulic System Circuits	7
	Oil Filter	9
	Control Valve Assembly (HPL)	9


BUY NOW
PayPal
VISA
MasterCard
DISCOVER
AMERICAN EXPRESS